



EN ISO
9001:2008 / 13485:2003



REV.00(04.04.2013)

HUMIDIFIER HEATER WIRE ADAPTERS

FMT® is registered trademark of Metko Ltd. Other products, logos and company names mentioned herein maybe trademarks of their respective owners and are not to be taken as an endorsement or affiliation with FMT®. The information in this instruction insert has been carefully checked and it is believed to be accurate. In the interest of continued product development, Metko reserves the right to make changes and improvements to this insert and the product it described any time, without notice or obligation.



<http://www.metkold.com/eng/humidifier.htm>

HWA Series Heater Wire Adapters are used to provide electrical energy from the humidifier to the heater wire of disposable or reusable heated breathing circuits. Dual or Single limb Adapters are available. HWA Series Heater Wire Adapters do not have surge and over-current protection circuit.

	 <p>Heater Wire Adapter for RT Series disposable heated breathing circuits</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-001 (OEM P/N F&P 900MR801, DRAGER 8414992)</p>
	 <p>Heater Wire Adapter for RT Series disposable dual heated breathing circuits</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-002 (OEM P/N F&P 900MR800, DRAGER MP01006)</p>
	 <p>Heater Wire Adapter for reusable heated breathing circuits with LEMO connector.</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-003 (OEM P/N F&P 900MR858, DRAGER 8414968)</p>
	 <p>Heater Wire Adapter for reusable dual heated breathing circuits with LEMO connector.</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-004 (OEM P/N F&P 900MR856)</p>
	 <p>Heater Wire Adapter for disposable heated breathing circuits with Molex connector.</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-005 (OEM P/N F&P 900MR859, DRAGER MP01001)</p>
	 <p>Heater Wire Adapter for disposable dual heated breathing circuits Molex connector.</p> <p>For use with MR850, HC550 Humidifiers</p> <p>REF: HWA-006 (OEM P/N F&P 900MR855)</p>



Heater Wire Adapter for RT Series disposable heated breathing circuits

For use with MR730 Humidifiers

REF: **HWA-007** (OEM P/N F&P 900MR901)



Heater Wire Adapter for RT Series disposable dual heated breathing circuits

For use with MR730 Humidifiers

REF: **HWA-008** (OEM P/N F&P 900MR900)



Heater Wire Adapter for reusable heated breathing circuits with LEMO connector.

For use with MR730 Humidifiers

REF: **HWA-009** (OEM P/N F&P 900MR558)



Heater Wire Adapter for reusable dual heated breathing circuits with LEMO connector.

For use with MR730 Humidifiers

REF: **HWA-010** (OEM P/N F&P 900MR556)



Heater Wire Adapter for disposable heated breathing circuits with Molex connector.

For use with MR730 Humidifiers

REF: **HWA-011** (OEM P/N F&P 900MR554)



Heater Wire Adapter for disposable dual heated breathing circuits Molex connector.

For use with MR730 Humidifiers

REF: **HWA-012** (OEM P/N F&P 900MR555)

► Heater Wire Breathing Circuit Connectors



RT / F&P Type
(Disposable)




RT / F&P Type
(Disposable)



Molex Type
(Disposable)



LEMO Type
(Reusable)



HEADQUARTER & FACTORY

İvedik O.S.B. Ağaç İşleri Sanayi Sit.
1354. Cad. 1358.Sok. No:9
06378 Yenimahalle

ANKARA / TÜRKİYE

Tel (pbx) : +90 312 387 12 46
Fax : +90 312 387 12 51

BRANCH

Atatürk Mah. Sedef Cad. 38 Ada
Ata Plaza 3-5 Blokları Kat:2 No:57
34758 Ataşehir

İSTANBUL / TÜRKİYE

Tel (pbx) : +90 216 455 91 21
Fax : +90 216 455 48 24

INTERNET

<http://www.metkold.com>
metko@metkold.com